

BRAUN

MultiQuick 9



Type 4200

Register your product
www.braunhousehold.com/register

Hand blender

English

11

عربي



26

© Copyright 2020. All rights reserved
De'Longhi Braun Household GmbH
Carl-Ulrich-Straße 4
63263 Neu-Isenburg/Germany


5722113844/04.20

MQ 9087XL-9098XL INT
UK/AR








B




C




D










	Parmesan 							
	1cm							
max.	100 g	10 g	90g+	50 g	7	80 g	80 g	100 g
speed								
() sec.	10	5	30 - 45	5	5	5	5	10



max.	95 g	30 g	20g/5	60 g	40 g	90 g	130 g	60 g	100 g	30g	20 g	150 g
speed												
















		Parmesan							
		1cm		1cm					
max.	700 g	500 g	40 g	4	500 g	600 g	400 g	600 g	600 g
speed									
(L) sec.	30	20-60	15	60	10-15	30-60	40	10-15	15










max.	500 g	500 g	300 g	500 g	500 g	300 g	500 g	
speed								
(L) sec.			60				60	















G



		Parmesan				
speed						



H





speed





English

Our products are engineered to meet the highest standards of quality, functionality and design. We hope you thoroughly enjoy your new Braun appliance.

Before use

Please read the user instructions carefully and completely before using the appliance and retain for future reference. Remove all packaging and labels and dispose them appropriately.

Caution

-  The blades are very sharp! To avoid injuries, please handle blades with utmost care.
- Care shall be taken when handling the sharp cutting blades, emptying the bowl and during cleaning.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Children shall not play with the appliance.
- This appliance shall not be used by children.
- Children shall be kept away from the appliance and its main cord.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Always switch off and unplug the appliance when it is left unattended and before assembling, disassembling, cleaning and storing.
- Before plugging into a socket, check whether your voltage corresponds with the voltage printed on the bottom of the appliance.
- This appliance is designed for household use only and for

processing normal household quantities.

- Do not use the appliance for any purpose other than the intended use described in the user manual. Any misuse may cause potential injury.
- Do not use any part in the microwave.
- Please clean all parts before first use or as required, following the instructions in the Care and Cleaning section.

Parts and Accessories

- 1 Pilot light
- 2 Safety button 
- 3 Smartspeed switch / variable speeds 
- 4 Motor part
- 5 EasyClick Plus release buttons
- 6 ActiveBlade shaft
- 7 Beaker
- 8 Whisk accessory
 - a Gearbox
 - b Whisk“
- 9 Puree accessory
 - a Gearbox
 - b Puree shaft
 - c Paddle“
- 10 350 ml chopper accessory «hc»
 - a Lid
 - b Chopping blade
 - c Chopper bowl
 - d Anti-slip rubber ring“
- 11 Coffee and Spice Grinder accessory
 - a Lid with coupling
 - b Grinder knife
 - c Bowl
 - d Anti-slip-base / lid
- 12 2000 ml food processor accessory with Dicer «fpl»
 - a Lid (with Gearbox)
 - b Coupling for motor part
 - c Pusher
 - d Feed tube
 - e Lid latch
 - f Splash Guard
 - g Food processor bowl
 - h Anti-slip rubber ring
 - i Chopping blade
 - j Chopping blade cover
 - k Dough Tool (FP)
 - l Kneading hook (Dicer)
 - m Dicer Blade
 - n Dicer Base
 - o Cleaning pusher

- p Insert holder
 - (i) Slicing insert (fine, coarse)
 - (ii) Shredding inserts (fine, coarse)
 - (iii) Julienne insert
- q French fries disc
- r Disc axle

Pilot Light

The pilot light (1) shows the status of the appliance, when it is connected to an electrical outlet.

Pilot light	Appliance / Operating status
Flashing red	Appliance is ready for use.
Solid green	Appliance is released (switch release button is pressed) and can be switched on.
Solid orange	Early warning about overheating. Motor slows down, step by step, till shut off.
Solid red	Let the device cool down one hour. It is ready for use again when the pilot light flashes red.

If the maximum speed decreases under high load and long running time you can still finish your preparation, however you should let the appliance cool down afterwards.

How to Use the Appliance

Smartspeed Switch for Variable Speeds

One squeeze, all speeds. The more you press, the higher the speed. The higher the speed, the faster and finer the blending and chopping results.

One handed operation: the Smartspeed switch (3) allows you to turn on the appliance and control the speed with one hand.

Operating your Hand Blender

First use: Remove the transportation lock from the motor part (4) by pulling it at the red strap.

Switching On (A)

The appliance comes equipped with a safety button for releasing the Smartspeed switch. To safely turn it on, follow these points:

- Press the safety button (2) with your thumb. The Pilot Light will turn solid green.
- Immediately press the Smartspeed switch and adjust to the desired speed.

NOTE: If the Smartspeed switch is not pressed within 2 seconds, the appliance cannot be switched on for safety reasons. The pilot light will flash red. To switch the appliance on, start again with first step.

- During operation you do not need to keep the safety button pressed.

ActiveBlade Shaft (B)

The hand blender is equipped with an ActiveBlade shaft, which enables the knife extend to the bottom of the bell. The adjustment is made automatically by pressure required in blending tasks, especially suited to mix hard foods e.g. raw fruits and vegetables.

It is also perfectly suited for preparing dips, sauces, salad dressings, soups, baby food, as well as drinks, smoothies and milkshakes.

For best results, use the highest speed.

Assembly and Operation

- Attach the ActiveBlade shaft (6) to the motor part until it clicks.
- Place the ActiveBlade shaft into the mixture to be blended. Then switch the appliance on as described above.
- Blend ingredients to the desired consistency using a gentle up-and-down motion. Depending on the pressure applied, the ActiveBlade shaft will depress and blade will extend.
- After use, unplug the hand blender and press the EasyClick Plus release buttons (5) to detach the ActiveBlade shaft.

Caution

- Do not let liquids or ingredients overlap the green line of the ActiveBlade shaft.
- If using the appliance to purée hot food in a saucepan or pot, remove the saucepan or pot from the heat source and ensure the liquid is not boiling. Allow hot food to cool slightly to avoid risk of scalding.
- Do not let the hand blender sit in a hot pan on the cooktop when not in use.
- Do not scratch the ActiveBlade shaft over the bottom of pans and pots.

Recipe Example: Mayonnaise

250 g oil (e.g. sunflower oil)

1 egg and 1 extra egg yolk

1–2 tbsp. Vinegar

Salt and pepper to taste

- Place all ingredients (at room temperature) into the beaker in the order as above.
- Place the hand blender at the bottom of the beaker. Blend at maximum speed until the oil starts emulsifying.
- With the hand blender still running, slowly raise the shaft to the top of the mixture and back down

to incorporate the rest of the oil.

NOTE: Processing time: approx. 1 minute for salads and up to 2 minutes for a thicker mayonnaise (e.g. for dip).

Whisk Accessory (B)

Use the whisk only for whipping cream, beating egg whites, making sponge cakes and ready-mix desserts.

Assembly and Operation

- Attach the whisk (8b) to the gearbox (8a).
- Align the motor part with the assembled whisk accessory and push the pieces together until they click.
- After use, unplug and press the EasyClick Plus release buttons to detach the motor part. Then pull the whisk out of the gearbox.

Tips for Best Results

- Move the whisk clockwise while holding it at a slight incline.
- To prevent splattering, start slowly and use the whisk accessory in deep containers or pans.
- Place the whisk in a bowl and only then switch the appliance on.
- Always ensure the whisk and mixing bowl are completely clean and free of fat before whisking egg whites. Only whip up to 4 egg whites.

Recipe Example: Whipped Cream

400 ml chilled cream (min. 30% fat content, 4 - 8 °C)

- Start with low speed (light pressure on the Smartspeed switch) and increase the speed (more pressure on Smartspeed switch) while whipping.
- Always use fresh chilled cream to achieve greater and more stable volume when whisking.

Puree Accessory (C)

The puree accessory can be used to mash cooked vegetables and fruits such as potatoes, sweet potatoes, tomatoes, plums and apples.

Before Use

- Do not mash hard or uncooked food, as this may damage the unit.
- Peel and remove any stones or hard parts; cook and drain then mash the fruit/vegetable.

Assembly and Operation

- Fit the gearbox (9a) to the shaft (9b) by turning in a clockwise direction until it locks into place.
- Turn the puree accessory upside down and fit the paddle (9c) over the central hub and turn counter-clockwise to locate. (If the gearbox is not fitted properly, then the paddle will not secure in place.)

- Align the assembled puree accessory with the motor part and click the two parts together. Plug in.
- Dip the puree accessory into the ingredients and switch on the appliance.
- Using a gentle up and down motion, move the puree accessory through the ingredients until the desired texture is achieved.
- Release the Smartspeed switch and ensure the puree accessory has completely stopped turning before removing it from the food.
- After use, unplug the appliance. Remove the paddle (9c) by turning clockwise.
- Press the EasyClick Plus release buttons to detach the puree accessory from the motor part. Separate the gearbox from the shaft by turning counterclockwise.

Caution

- Never use the puree accessory in a saucepan over direct heat.
- Always remove the saucepan from the heat and allow to cool slightly.
- Sit the saucepan or bowl on a stable, flat surface, and support it with your free hand.
- Do not tap the puree accessory on the side of the cooking vessel during or after use. Use a spatula to scrape excess food away.
- For best results when mashing never fill a saucepan or bowl more than half full with food.
- Do not process more than one batch without interruption.
- Let the appliance cool down for 4 minutes before you continue processing.

Recipe Example: Mashed Potatoes

1 kg cooked potatoes

200 ml warm milk

- Place the potatoes in a bowl and mash for 30 seconds (3/4 way on the Smartspeed switch).
- Add the milk. Resume mashing for another 30 seconds.

Chopper Accessory (D)

The chopper (10) is perfectly suited for chopping hard cheese, onions, herbs, garlic, vegetables, bread, crackers and nuts.

Use the «hc» chopper (10) for fine results. It is not suitable for meat.

For «hc» chopper do not exceed the quantity of ingredients higher than max line. Maximum operation time for the «hc» chopper: 1 minute for large amounts of wet ingredients, 30 seconds for dry or hard ingredients.

NOTE: leave an interval of at least 3 minutes before operating again (To prevent faults). Immediately stop processing when motor speed decreases and/or strong vibrations occur.

Refer to the Processing Guide D for maximum quantities, recommended times and speeds.

Before Use

- Pre-cut foods into small pieces for easier chopping.
- Remove any bones, tendons and gristle from meat to help prevent damage to the blades.
- Make sure the anti-slip rubber ring (10d) is attached to the bottom of the chopper bowl.

Assembly and Operation

- Carefully remove the plastic cover from the blade.
- The blade (10b) is very sharp! Always hold it by the upper plastic part and handle it carefully.
- Place the blade on the center pin of the chopper bowl (10c). Press it down and give it a turn so that it locks into place.
- Fill the chopper with food and put on the lid (10a).
- Align the chopper with the motor part (4) and click together.
- To operate the chopper, switch on the appliance. During processing, hold the motor part with one hand and the chopper bowl with the other.
- Always chop harder foods (e.g. parmesan cheese) at full speed.
- When chopping is complete, unplug and press the EasyClick Plus release buttons (5) to detach the motor part.
- Lift the lid up. Carefully take out the blade before pouring out the contents of the bowl. To remove the blade, slightly turn it then pull it off.

Caution

- Do not use the chopper accessory to process extremely hard foods, such as unshelled nuts, ice cubes, coffee beans, grains, or hard spices e.g. nutmeg. Processing these foods could damage the blades.
- If using the appliance to purée hot food ensure the liquid is not boiling. Allow hot food to cool slightly to avoid risk of scalding.
- Never place the chopper bowl in the microwave oven.

«hc» Recipe example: Honey-Prunes (as a pancake stuffing or spread)

50 g prunes

75 g creamy honey

70 ml water (vanilla-flavour)

- Fill the «hc» chopper bowl with prunes and creamy honey.
- Store at 3 °C in refrigerator for 24 hours.
- Add 70 ml water (vanilla-flavoured).
- Chop 1,5 seconds at maximum speed (fully press the Smartspeed switch).

Coffee and Spice Grinder Accessory (E)

The grinder is perfectly suited for grinding any kind of dry spices or other ingredients, such as pepper, cloves, chili, coffee or soya beans, rice, poppy seeds, sugar, dried sardines and shrimps.

For finest results, use the highest speed.

Assembly and Operation

- Make sure the anti-slip rubber base (11d) is attached to the bottom of the bowl.
- Always hold the grinder knife (11b) by the upper plastic part and handle it carefully.
- Place the blade on the center pin of the grinder bowl (11c) and spin it slightly so that it drops down and locks into place.
- Fill the grinder with ingredients and put on the lid with coupling (11a).
- Grind ingredients to the desired consistency.
- When grinding is complete, unplug and press the EasyClick Plus release buttons to detach the motor part.
- Lift the lid up. Take out the blade before pouring out the contents of the grinder bowl.

Caution

- Always just fill until max. line within the grinder.
- Only to be used for dry ingredients.
- Allow spices to cool down to room temperature before grinding.
- It is not recommended to grind corn, walnuts, baking chocolate, rock candy and hard cheese.
- Never place the grinder bowl in the microwave oven.

Refer to the Processing Guide A for maximum quantities and speeds.

Maximum operation time for the grinder is 20 seconds.

Food Processor Accessory with Dicer

The food processor accessory with Dicer (12) can be used for:

- Chopping, blending and mixing Pancake batter;
- kneading dough and preparing cake batter, based on max. 500 g flour (cake batter is only possible with models containing the dough tool (12k);
- slicing, shredding, juliennning, and making french fries.
- dicing.

Chopping (F)

Using the blade (12i) you can chop meat, hard cheese, onions, herbs, garlic, vegetables, bread, crackers, and nuts.

Refer to the Processing Guide E for maximum quantities, recommended times and speeds.

Before Use

- Pre-cut foods into small pieces for easier chopping
- Remove any bones, cartilage, tendons and gristle from meat to help prevent damage to the blades.
- Remove stems from herbs, shell nuts.
- Make sure the anti-slip rubber ring (11g) is attached to the bottom of the food processor bowl.

Assembly and Operation

- Carefully remove the chopper blade cover (12j) from the blade.
- The blade (12i) is very sharp! Always hold it by the upper plastic part and handle it carefully.
- Place the blade on the center pin of the bowl (12g). Press it down and give it a turn so that it locks into place.
- Fill the bowl with food. Insert the splash guard (12f).
- Then put on the lid (12a) until it engages with a click.
- Insert the motor part (4) into the coupling (12b) until it locks.
- Plug in the appliance and insert the pusher (12c) in the feed tube (12d).
- To operate the food processor, switch on the appliance. During processing, hold the motor part with one hand and the food processor bowl on the handle.
- When chopping is complete, unplug and press the EasyClick Plus release buttons (5) to detach the motor part.
- Press the lid latch (12e) to lift up the lid. Then separate the lid from splash guard.
- Carefully take out the blade before pouring out the contents of the bowl. To remove and unlock the blade, slightly turn it then pull it off.

Caution

- Do not use the food processor accessory to chop extremely hard foods, such as unshelled nuts, ice cubes, coffee beans, grains or hard spices e.g. nutmeg. Processing these foods could damage the blades.
- Never place the food processor bowl in the microwave oven.

Using the blade (12i), you may also mix pancake batter based on up to 500 g of flour.

Recipe Example: Pancake Batter

- 750 ml milk
500 g plain flour
4 eggs
- Pour milk into the bowl, then add flour and finally the eggs.
 - Using full speed, mix the batter until smooth.

Heavier batters or doughs must not be prepared with the knife. Use the Dough Tool or Kneading hook (F) for heavier batters and doughs.

Dough Tool and Kneading Hook (F)

Figure F also applies (depending on model) for the use of the dough tool (12k) and the kneading hook (12l).

The dough tool is ideal for kneading and mixing different doughs such as yeast or pastry and mixing sponge mixtures.

The kneading hook is ideal for kneading different dough types such as yeast or pastry.

Refer to the Processing Guide Kneading F for maximum quantities, recommended times and speeds.

Assembly and Operation

- Place the dough tool / kneading hook on the center pin of the bowl (12g). Press it down and give it a turn so that it locks into place.
- Fill the bowl with flour (max. 500 g), then add the other ingredients except the liquids.
- Turn the appliance on at maximum speed.
- Add liquids through the feed tube while the motor is running.

NOTE: Maximum kneading time: 1 minute – then allow the motor to cool down for 10 minutes.

Recipe Example: Pizza dough

- 500 g plain flour
1 tsp. salt
1 tsp. dried yeast
10 tbsp. olive oil
300 ml water (lukewarm)
- Put all ingredients except water into the bowl and start kneading.
 - Add water through the feed tube while the motor is running.

Recipe Example: Sweet Pastry

- 300 g plain flour
340 g unsalted butter (cold/hard, small pieces)
160 g sugar
2 vanilla sugar
2 small egg
2 pinch salt
- Put butter and sugar into the bowl and start kneading. For good results use cold butter.
 - Add flour and the rest of the ingredients.
 - Dough will become too soft from over kneading. Stop kneading shortly after dough has formed a ball.
 - Cool down the dough in the refrigerator for half an hour before proceeding.

Recipe Example FP: Cake Batter

- 500 g plain flour
200 g sugar

200 g unsalted butter

3 eggs

1 vanilla sugar

1 baking powder

200 ml milk

- Add flour and all other ingredients except the milk into the bowl and start kneading.

- Gradually add milk while running until uniform mass has formed.

Recipe Example Dicer: Sweet dough

500 g plain flour

80 g sugar

80 g unsalted butter

1 egg

7 g yeast

200 ml milk

- Add flour and all other ingredients except the milk into the bowl and start kneading.
- Gradually add milk while running until and slowly knead the mass dough until it forms a ball that no longer sticks to the bowl.
- Let the dough rise in a warm place for 2 hours.

Slicing / Shredding / Julienne / French Fry (G)

Use the fine and coarse slicing inserts (i) to slice raw fruit and vegetables into fine, thin slices; e.g. cucumbers, onions, mushrooms, apples, carrots, radishes, potatoes, zucchini and cabbage.

Use the fine and coarse shredding inserts (ii) to shred foods such as apples, carrots, potatoes, beetroot, cabbage, hard cheese (like Parmesan).

Use the julienne insert (iii) to cut fruit and vegetable into julienne.

Use the French fry disc (12q) to prepare french fries.

Refer to the Processing Guide G for recommended speeds.

Assembly and Operation

- Reach into the holes of the Insert holder (12p) or French fry Disc (12q) to attach the Disc axle (12r) and turn it to the left, until it locks.
- For slicing and shredding place an insert into the insert holder (12p) and snap into position. Make sure that the insert is fully inserted into the insert holder and no offset remains. Place the assembled insert holder or French fry disc on the center pin of the bowl and give it a turn so that it locks into place.
- Insert the splash guard (12f) to the bowl and put on the lid (12a) until it engages with a click.
- Insert the motor part into the coupling until it locks.
- Plug in the appliance and insert the food to be processed into the feed tube.
- For best French fry results, place 3-4 potatoes (depending on the size) in the feed tube of the lid while the motor is switched off.

- Switch the appliance on to operate. Never reach into the feed tube when the appliance is switched on. Always use the pusher to feed in food.
- After use, unplug and press the EasyClick Plus release buttons to detach the motor part.
- Press the lid latch (12e) to lift up the lid. Then separate the lid from splash guard.
- Carefully take out insert holder or French fry disc before pouring out the contents of the bowl. To remove the insert holder or French fry disc, slightly turn it then take it out with reaching into the holes with the fingers.
- To remove an insert, push it up at the one end that protrudes at the bottom side of the insert holder.

Dicing (H)

Use the Dicer to cut raw and cooked vegetables and fruits into small cubes e.g. for salads, soups and desserts.

Refer to the Processing Guide H for recommended speeds.

Before Use

- Remove pip and stones from fruits. Frozen food is not allowed to prevent damage to the blades.
- Make sure the anti-slip rubber ring (12h) is attached to the bottom of the food processor bowl.

Assembly and Operation

- Before first use, carefully remove the paper guard from the cutting edge of the Dicer blade (12m) and discard it.
- Place the Dicer blade on the center Pin of the Dicer Base (12n) and turn it until it locks into place.
- Align the splash guard and the assembled Dicer unit with the markings aligned to each other and turn it counter-clockwise until the units are firmly connected.
- Place the assembled Dicer unit in the bowl and put on the lid until it clicks into place.
- Insert the motor part into the coupling until it locks.
- Plug in the appliance and insert the food to be processed into the feed tube.
- Switch the appliance on to operate. Never reach into the feed tube when the appliance is switched on. Always use the pusher to feed in food.
- After use, unplug and press the EasyClick Plus release buttons to detach the motor part.
- Press the lid latch (12e) to lift up the lid. Then separate the lid from splash guard.
- To disassemble the Dicer unit, turn the splash guard clockwise until the lock opens.
- Carefully remove the Dicer blade by turning and lifting it up.
- Turn the Dicer base upside down and use the Cleaning pusher (12o) to remove any leftover.

Tips for Best Results

- Cooked food needs to cool down before dicing, as results will be firmer and better.
- Medium-hard cheese like Emmentaler can be processed; very soft or very hard cheese like young Gouda, Mozzarella or Parmesan can't be processed.
- If you are processing different foods in one preparation, always start with the softest one and finish with the hardest one. This way you can process all foods without cleaning the grid in between.
- The Dicer is not suitable to process raw meat.
- Peel vegetables (especially potatoes and vegetables with hard skin like squash) before processing. Otherwise skins can get caught in the cutting grid, increasing the cleaning effort.

Caution

- The blades are very sharp. Only handle the parts by the plastic components.
- Do not use the food processor accessory with Dicer to process extremely hard foods, such as unshelled nuts, ice cubes, coffee beans, grains or hard spices e.g. nutmeg. Processing these foods could damage the blades.
- Empty bowl before it is completely full.
- After processing greasy foods, the Dicer Blade can get slippery. Take special care when removing.
- The cleaning pusher can only be used from the bottom side of the Dicer Base. Using from above could shave the plastic pieces off the cleaning pusher.
- Never place the food processor bowl in the microwave oven.

Recipe Example: Salad «Olivier»

6 boiled, cooled potatoes

150 g cooked sausage

6 hard boiled eggs

2 boiled carrots

4 gherkins

1 can of peas

400 g mayonnaise

200 g sour cream

Parsley and dill herbs

Salt and pepper to taste

- Dice eggs, cooked sausages, carrots, gherkins and potatoes at full speed.
- Mix all diced ingredients with the peas in a salad bowl.
- Season to taste with salt, pepper, parsley and dill herbs and dress with mayonnaise and sour cream.

- Do not immerse the motor part (4) or gearboxes (8a, 9a, 12a) in water or any other liquid. Clean with a damp cloth only.
- To reuse the grinder knife make sure that it is absolutely dry after cleaning.
- All other parts can be cleaned in a dishwasher. Do not use abrasive cleaners that could scratch the surface.
- You may remove the anti-slip rubber rings from the bottom of the bowls for an extra thorough clean.
- When processing foods with high pigment content (e.g. carrots, or curcuma), the accessories may become discolored. Wipe these parts with vegetable oil before cleaning them.

Warranty and Service

For detailed information see separate warranty and service leaflet or visit www.braunhousehold.com.

Both the design specifications and these user instructions are subject to change without notice.

Please do not dispose of the product in the household waste at the end of its useful life. Disposal can take place at appropriate collection points provided in your country.

Materials and accessories coming into contact with food conform to EEC regulation 1935/2004..



Care and Cleaning (I)

- Always clean the hand blender and the suitable accessories thoroughly for first use and after every use with water and detergent.
- Unplug hand blender before cleaning.

Troubleshooting guide

Problem	Possible cause	Solution
Hand blender does not operate.	No power	Check appliance is plugged in. Check the fuse /circuit breaker in your home. If none of the above contact Braun Service.
Lid (with Gearbox) cannot be closed completely	Food is trapped between FP bowl and lid (with Gearbox)	Open the lid (with Gearbox) and remove food residues
	Tool is not inserted into the FP bowl completely	Turn the tool by hand while pressing down slightly, until it locks in place
	Dicer only: The Dicer is not connected to the Splash Guard or not connected correctly	Attach the Dicer to the Splash Guard before placing the Lid (with Gearbox) in the FP bowl (observe the symbols for correct alignment)
	Dicer only: The Dicer is blocked by food residues in the cutting grid	Open the Dicer and remove food from the grid
	Is not connected correctly	Connect correctly
Water in the Lid (with Gearbox)	Lid (with Gearbox) was accidentally immersed in water or placed in the dishwasher	Remove rubber plug inside the coupling for motor part. Drain the water. Replace the plug. Caution: Water in the lid (with Gearbox) will damage the device. This described method must therefore not be used intentionally to place the lid (with Gearbox) in the dishwasher
Water in one of the tools (Dough tool, Kneading hook, Blade or Disc Axle)	Leakage of the affected tool	Contact a Braun service center for replacement
Pilot light shows solid red	Device is overheated.	Let the device cool down one hour. It is ready for use again when the pilot light flashes red.

الحل	الأسباب المحتملة	المشكلة
تحقق من توصيل الجهاز بالكهرباء. تحقق من المنصهر/قطاع الدائرة في منزلك. إذا لم يجِد أي شيء مما سبق نفعاً، فاتصل على خدمة Braun.	لا توجد طاقة كهربائية	الخلط اليدوي لا يعمل.
افتتح الغطاء (مزود بصندوق تروس) وقم بإزالة بقايا الطعام	الطعام محصور بين وعاء FP والغطاء (مزود بصندوق تروس)	
اقلب الأداة باليد مع الضغط لأسفل قليلاً حتى يتم قفلها في مكانها	لا يتم إدراج الأداة في وعاء FP بالكامل	
قم بتوصيل القطاعة بلوحة الحماية من الرذاذ قبل وضع الغطاء (مزود بصندوق تروس) في وعاء FP (لاحظ الرموز للمحاذنة الصحيحة)	القطاعة فقط: القطاعة غير متصلة بلوحة الحماية من الرذاذ أو غير متصلة بشكل صحيح	لا يمكن إغلاق الغطاء (مزود بصندوق تروس) بالكامل
افتتح القطاعة وقم بإزالة الطعام من الشبكة	القطاعة مسدودة بسبب بقايا الطعام الموجودة في شبكة التقطيع	
قم بتوصيلها بشكل صحيح	ليست متصلة بشكل صحيح	
أزل السدادة المطاطية بداخل قارنة جزء المотор. قم بتصريف الماء. استبدل السدادة. تحذير: سوف يحمل الماء في الغطاء (مزود بصندوق تروس) على إتلاف الجهاز. لذلك يجب عدم استخدام هذه الطريقة الموضحة عمداً لوضع الغطاء (مزود بصندوق تروس) في غسالة الصحون	تم غمر الغطاء (مزود بصندوق تروس) في الماء أو وضعه في غسالة الصحون	ماء في الغطاء (مزود بصندوق تروس)
اتصل بمركز خدمة Braun للاستبدال	تسرب بالأداة المتضررة	الماء في واحدة من الأدوات (اداة العجين، خطاف العجن، الشفرة أو محور القرص)
دع الجهاز يبرد لمدة ساعة واحدة. يصبح جاهزاً للستخدام مرة أخرى عندما يومنض النور الدليلي باللون الأحمر.	لقد ارتفعت درجة حرارة الجهاز عن الحد المسموح.	يعرض النور الدليلي لوناً أحمر ثابتاً

للحصول على معلومات تفصيلية، انظر نشرة الضمان والخدمة المنفصلة أو
www.braunhousehold.com. تفضل بزيارة

تخضع كل من مواصفات التصميم وتعليمات المستخدم هذه للتغيير دون
إشعار مسبق.

«يرجى عدم التخلص من المنتج ضمن المخلفات المنزلية عند
نهاية فترة الصلاحية للاستخدام. يمكن أن يتم التخلص من
أو في نقاط التجميع Braun الجهاز في مركز خدمات
المناسبة التي توفرها دولتك.»

تطابق المواد والملحقات التي تتصل باستعمال المواد الغذائية مع لوائح
الاتحاد الأوروبي الاقتصادية رقم 1935/2004.

- قيم بتقشير الخضروات (خاصة البطاطا والخضروات ذات القشرة الخارجية الصلبة مثل القرع) قبل التحضير . بخلاف ذلك يمكن أن تتعلق القشور الخارجية في شبكة التقاطيع ، مما يزيد من جهود التنظيف .

تحذير

- الشفرات حادة للغاية. فقط تعامل مع الأجزاء من خلال المكونات البلاستيكية.
 - لا تستخدم ملحق جهاز تحضير الطعام مع القطاعة لتحضير الأطعمة الصلبة للغاية، مثل البندق غير المقشر أو مكعبات الثلج أو حبوب القهوة أو الحبوب أو الأعشاب القوية مثل جوز الطيب. قد يؤدي تحضير هذه الأطعمة إلى تلف الشفرات.
 - قم بفتح الوعاء قبل امتلاكه بالكامل.
 - بعد تحضير الأطعمة الدهنية، يمكن أن تصبح شفرة القطاعة زلقة. توخ الحذر عند إزالتها.
 - لا يمكن استخدام دافعة التنظيف إلا من الجانب السفلي لقاعدة القطاعة. يمكن أن يتسبّب الاستخدام من الأعلى في كشط القطع البلاستيكية على دافعة التنظيف.
 - لا نضع وعاء حمام تجفيف الطعام أبداً في فن الميكرويف.

مثال لوصفة: سلطة «أوليفير»
 6 ثمرات بطاطا مسلوقة ومببردة
 150 جرام من التفانق المطهوة
 6 بيضات مسلوقة جيداً
 2 جزءة مسلوقة
 4 ثمرات من الخيار
 1 علبة من البازلاء
 400 جرام من المايونيز
 200 جرام من الكريمة الحامضة
 البقدونس والشبت
 ملح وفلفل للطعم

الرعاية والتنظيف (I)

- نظف دائمًا الخلط اليدوي والملحقات المناسبة جيداً عند الاستخدام لأول مرة وبعد كل استخدام بالماء والمنظفات.
 - افصل الطاقة عن الخلط اليدوي قبل التنظيف.
 - لا تغمر جزء المотор (4) وعلبة تروس السرعة (8a, 9a, 12a) في الماء أو أي سائل آخر.
 - نظف باستخدام قطعة قماش مبللة فقط.
 - تأكد بند إعادة استخدام سكين المطحنة أنها جافة تماماً بعد التنظيف.
 - يمكن تنظيف باقي الأجزاء في غسالة الأطباق. لا تستخدم المنظفات الكاشطة التي يمكن أن تخدش السطح.
 - يمكن إزالة الحالات المطاطية المنزلقة من أسفل الأوعية لتنظيفها بطريقة أفضل.
 - عند تغيير الأطعمة التي تحتوي على أصباغ مرتفعية (على سبيل المثال، الجزر أو الكركم)، فقد يزول لون الأجهزة الملحقة. ادهن هذه الأجزاء بزيت بخضروات قبل غسلها.

EasyClick Plus لفص جزء المотор.
اضغط مراج الغطاء (12e) لرفع الغطاء لأعلى
لوحة الحماية من الرذاذ.
قم بإخراج حامل المُلْحَق أو قرص قطع السك المُستويات من الواقع، لإزالة حامل الـ
البطاطا المقليّة، لفه قليلاً ثم أخرجه للوصول
إلى زلة أداء، ادفعه للأعلى حتى تصل إلى
حاجم الأداة.

قطعه ف، شکا، مکعبات (H)

- تخدم القطاعات لقطع الخضروات والفواكه النية والمطهوة إلى مكعبات غرفة، على سبيل المثال للسلطات والشوربات والحلويات.

مع دليل التحضير و للساعات المُوصى بها.

الاستخدام

- أول البنزور واللوي من الفواكه. لا يُسمح بالأطعمة المجمدة منعاً لتأثر الشفارات.

ثاكار من إرافق الحلة المطاطية المانعة للانزلاق (12h) أسفل وعاء جهاز تجسس الطعام.

جمع والتضليل

- قبل الاستخدام الأول، أخرج الواقي الورقي بعناية من نصل القطع بشفرة القطعة (12m) وتخليص منها.

ضع شفرة القطعة في منتصف قاعدة القطعة (12n) وقم بلفها حتى يتم تأمينها في مكانها.

قم بمحاذاة لوحه الحماية من الرذاذ ووحدة القطعة المجمعة مع العلامات المعاذية لبعضها البعض وقم بلفها في اتجاه عقارب الساعة حتى يتم توصيل الوحدات بإحكام.

ضع وحدة القطعة المجمعة في الوعاء وضع الغطاء حتى تسمع صوت نقرة عند وضعه في مكانه.

ادخل جزء المотор في الوصلة حتى يتم تأمينه.

وصل الجهاز بقابس الكهرباء وضع الطعام المطلوب تحضيره في أنبوب التغذية.

شغل الجهاز على وضع التشغيل. لا تلمس أنبوب التغذية أثناء تشغيل الجهاز. استخدم الدافع دائمًا لتلقيمه بالطعام.

وبعد الاستخدام، افصلي الطاقة واضغطي على أزرار التحرير لفصل جزء المotor EasyClick Plus.

اضغط ملاجأ الطعام (12e) لرفع الطعام لأعلى. ثم افصل الطعام من لوحه الحماية من الرذاذ.

لذلك وحدة القطعة، أدر لوحه الحماية من الرذاذ في اتجاه عقارب الساعة حتى يفتح القفل.

قم بإزالة شفرة القطعة بعناية عن طريق لفها ورفعها لأعلى.

اقلب قاعدة القطعة رأساً على عقب واستخدم دافعة التنظيف (120) لإزاله أي بقايا.

طوات للحصول على أفضل النتائج

- يجب أن يبرد الطعام المطهو قبل التقطيع إلى مكعبات، لأن النتائج ستكون أكثر ثباتاً وأفضل.

يمكن تحضير الجنين متوسط الصلابة مثل إمتنال؛ ولا يمكن تحضير الجنين الناعم جداً أو شديد الصلابة مثل جين غاوادا الجديد أو الموزان، أو البارميرزان.

إذا كنت تقوم بتحضير الأطعمة المختلفة في الوقت نفسه، فابدأ دائمًا بالأكثر تغومة واترك الأصلب للنهاية. بهذه الطريقة يمكنك تحضير جميع الأطعمة دون تنظيف الشبكة بينها.

القطاعنة غير مناسبة لتحضير اللحوم النيئة.

4 بيضات

- اسكب الحليب في الوعاء، ثم أضف الدقيق وأخيراً البيض.
- باستخدام السرعة الكاملة، اخلط العجينة حتى تصبح لينة.

يجب عدم إعداد عجائن البانكيك السائلة أو عجائن الخبز السميكة باستخدام السكين. استخدم أدأة العجين أو خطاف العجين (F) من أجل عجائن البانكيك السائلة أو عجائن الخبز السميكة.

أداة العجين وخطاف العجين (F)

ينطبق الشكل (F) أيضًا (حسب الطراز) لاستخدام أدأة العجين (12k) وخطاف العجين (12l).

تعتبر أدأة العجين مثالياً للعجن وخلط العجائن المختلفة مثل الخميرة أو الفطائر وخلط المخاليط الإسفنجية.

يعتبر خطاف العجين مثالياً لأنواع العجن الخفيف المختلفة مثل عجينة الخمير أو الفطائر.

راجع دليل التحضير فيما يتعلق بالعجن وللمعرفة الكميات القصوى والفترات الزمنية الموصى بها والسرعات.

التحميم والتشغل

- ضع أدأة العجين / خطاف العجين في منتصف الوعاء (12g). اضغط عليها لأسفل وقم بلفها حتى يتم تأمينها في مكانها.
- ابدأ الوعاء بالدقيق (بوزن 250 جرام كحد أقصى) ثم أضف المكونات الأخرى بحسب التسلسل.
- شغل الجهاز على أقصى سرعة.
- أضف السوائل من خلال أنبوب التغذية أثناء تشغيل المотор. ملاحظة: أقصى زمن للعجن هو: دقيقة واحدة - ثم اترك المотор يبرد لمدة 10 دقائق.

مثال لوصفة: عجينة البسترا

- | |
|--|
| 500 جرام دقيق عادي |
| 1 ملعقة ملح |
| 1 ملعقة طعام خميرة جافة |
| 10 ملاعق زيت زيتون |
| 300 ملي ماء (فاتر) |
| • ضع جميع المكونات بحسب التسلسل داخل الوعاء وابدأ العجن. |
| • أضف المياه من خلال أنبوب التغذية أثناء تشغيل المotor. |

مثال لوصفة: الفطائر الجلوة

- | |
|---|
| 300 جرام دقيق عادي |
| 340 جرام زبدة غير مملحة (مجمدة/صلبة، قطع صغيرة) |

- | |
|---|
| 160 جرام سكر |
| 2 سكر فانيليا |
| 2 بيضة صغيرة |
| 2 فرسنة ملح بأطراف الأصابع |
| • ضع الزبدة والسكر داخل الوعاء وابدأ العجن. للحصول على نتائج جيدة، استخدم زبدة مجمدة. |
| • أضف الدقيق وبقى المكونات. |
| • ستصبح العجينة ناعمة جداً من خلال العجن. أوقف العجن بعد فترة قصيرة من تشكيل العجينة إلى كرة. |
| • اترك العجين يبرد في الثلاجة لمدة نصف ساعة قبل المتابعة. |

مثال لوصفة PF: عجينة البانكيك السائلة

- | |
|--------------------|
| 500 جرام دقيق عادي |
| 200 جرام سكر |

- 200 جرام زبدة غير مملحة 3 بيضات
- 1 سكر فانيليا
- 1 مسحوق خبز
- 200 ملي حليب
- أضف الدقيق وجميع المكونات الأخرى باستثناء الحليب في الوعاء وابدأ العجن.
- أضف الحليب تدريجياً أثناء العمل حتى تتشكل كتلة موحدة.

مثال لوصفة قطاعة: عجينة حلو

- | |
|---|
| 500 جرام دقيق عادي |
| 80 جرام سكر |
| 80 جرام زبدة غير مملحة |
| 1 بيضة |
| 7 جرام خميرة |
| 200 ملي حليب |
| • أضف الدقيق وجميع المكونات الأخرى باستثناء الحليب في الوعاء وابدأ العجن. |
| • أضف الحليب تدريجياً أثناء العمل حتى يتم عجن كتلة العجين ببطء حتى تشكل كرة لا تلتصق بالوعاء. |
| • اترك العجين يختمر في مكان دافئ لمدة ساعتين. |

الشارائح / التقطيع / جولييان / أصابع البطاطا المقلية (G)

- استخدم أدوات الشارائح الناعمة والخشنة (11) لقطع الفواكه الطازجة والخضروات إلى شارائح ناعمة ورقية مثل الخيار والبصل وعش الغراب والتفاح والجزر والفجل والبطاطا والكوسا والكرنب.

استخدم ملحوظات التقطيع الناعمة والخشنة (ii) لقطع الطعام مثل التفاح والجزر والبطاطس والشمندر والكرنب والجبن الصلب (مثل جبن البرميجان).

استخدم أدأة جولييان (iii) لقطع الفاكهة والخضروات إلى جولييان.

استخدم قرص تقطيع البطاطا المقلية (12q) لإعداد أصابع البطاطا المقلية.

راجع دليل التحضير F للسرعات الموصى بها.

التحميم والتشغل

- قم بالوصول إلى فتحات حامل الملحق (12p) أو قرص تقطيع البطاطا المقلية (12q) لتوصيل محور القرص (12r) ولفه إلى اليسار، حتى يتم تأمينه.

• للحصول على شرائح وقطع صغيرة، ضع ملحق ما يدخل حامل الملحق (12p) وأطبقه في مكانه. تأكد من إدخال الملحق بالكامل في حامل الملحق وعدم وجود إزاحة. ضع حامل الملحق المجمع أو قرص تقطيع البطاطا المقلية في منتصف الوعاء ولفه حتى يتم تأمينه في مكانه.

- أدخل لوحه الحماية من الرذاذ (12f) في الوعاء ووضع الخطاء (12a) حتى يتم تركيبه بإحكام وتسعم صوت نقرة.
- أدخل جزء المотор في الوصلة حتى يتم تأمينه.

• وصل الجهاز بقباس الكهرباء وضع الطعام المطلوب تحضيره في أنبوب التغذية.

- للحصول على أفضل نتائج لأصابع البطاطا المقلية، ضع 4-5 بطاطات (حسب الحجم) في أنبوب التغذية للغطاء أثناء إيقاف تشغيل المotor.
- شغل الجهاز على وضع التشغيل. لا تلمس أنبوب التغذية أثناء تشغيل الجهاز. استخدم الدافع دائمًا لتلقيمه بالطعام.
- وبعد الاستخدام، افصلي الطاقة واضغطي على أزرار التحرير.

ملحق جهاز تحضير الطعام

• ارفع الغطاء لأعلى. قم بإخراج الشفرة بحرص قبل سكب المحتويات من الوعاء. لإزالة الشفرة، لها قليلاً ثم اسحبها.

تحذير

- لا تستخدم ملحق المفرمة لتحضير الأطعمة الصلبة للغاية مثل البندق غير المقشر أو مكعبات الثلج أو حبوب القهوة أو الحبوب أو الأعشاب القوية مثل حبوب الطيب. قد يؤدي تحضير هذه الأطعمة إلى تلف الشفرات.
- إذا كنت تستخدم الجهاز لهرس طعام ساخن، فتأكد من أن السائل لا يغلي. اترك الطعام الساخن يبرد قليلاً لتجنب مخاطرة التعرض للحرق.
- لا تضع أوعية المفرمة أبداً في فرن الميكروويف.

(F) الفرم

باستخدام الشفرة (12i) يمكنك فرم اللحم والجبن الصلب والبصل والأعشاب والثوم والخضروات والخبز والمكسرات والبندق.

راجع دليل التحضير هـ لأقصى الكميات والفترات الزمنية الموصى بها والسرعات.

قبل الاستخدام

- قم بقطع الطعام مسبيقاً إلى قطع صغيرة لتنقطع أسهل.
- أزل أية إيهام وأنسجة وغضاريف من اللحم لتساعد في حماية الشفرات من التلف.
- أزل السيقان من الأعشاب والقشور والنوى.
- تأكد من إرافق الحلقة المطاطية المانعة للانزلاق (12h) أسفل وعاء جهاز تحضير الطعام.

التجمیع والتخلیف

- أزل غطاء شفرة التقطيع (12j) بحرص من الشفرة.
- تُعتبر الشفرة (12i) حادة للغاية! لا تممس الشفرة إلا من الجزء البلاستيكي العلوي واستخدمه بحرص.
- املأ وعاء بالطعام. قم بإدراجه لوحة الحماية من الرذاذ (12f).
- لإغلاق الغطاء، لفه في اتجاه عقارب الساعة حتى يدخل المزلاج وتسمع صوت نقرة.
- أدخل جزء المотор (4) في الوصلة (12j) بـ حتى تُعلق.
- وصل الجهاز وأدخل الدافع (13d) في أنبوب التغذية (12c).
- لتشغيل جهاز تحضير الطعام، قم بتشغيل الجهاز. أثناء التحضير، امسك جزء المotor بيد واحدة ووعاء جهاز تحضير الطعام من المقبض.
- عند اكتمال الفرم، افصل الطاقة واضغط على أزرار التحرير EasyClick Plus (5).
- اضغط مزلاج الغطاء (12e) لرفع الغطاء لأعلى. ثم افصل الغطاء من لوحة الحماية من الرذاذ.
- قم بإخراج الشفرة بحرص قبل سكب المحتويات من الوعاء. لإزالة الشفرة وإلغاء تأمينها، لها قليلاً ثم اسحبها.

تحذير

- لا تستخدم ملحق غير المقشر أو مكعبات الثلج أو حبوب القهوة أو الحبوب أو الأعشاب القوية مثل حبوب الطيب. قد يؤدي تحضير هذه الأطعمة إلى تلف الشفرات.
- لا تضع وعاء جهاز تحضير الطعام أبداً في فرن الميكروويف.

باستخدام الشفرة (12i)، يمكنك أيضًا خلط عجينة البانكيك السائلة بكمية دقيقة لا تزيد عن 500 جرام.

مثال لوصفة: عجينة البان كيك

750 ملي حليب

500 جرام دقيق عادي

تحذير

- املأ دائماً حتى خط الحد الأقصى فقط داخل المطحنة.
- تستخدمن للمكونات الجافة فقط.
- دع التوابل تبرد إلى درجة حرارة الغرفة قبل الطحن.
- لا يوصى مطلقاً بطحن الذرة والجوز وشوكولاتة الجوز وسكر البنات والجبن الصلب.
- لا تضع وعاء المطحنة أبداً في فرن الميكروويف.

راجع دليل التحضير أولاً للاطلاع على الحد الأقصى لكميات والسرعات.

أقصى زمن تشغيل للمطحنة هو 20 ثانية.

- ضع الطنجرة أو الوعاء على مكان مستقر وسطح مستوٍ وقم بدعمه من خلال مسكه بيديك الحرة.
- لا تترك ملحق الهرس بجانب إثناء الطهي أثناء الاستخدام أو بعده. استخدم سكين لتنزع الطعام الزائد.
- للحصول على أفضل النتائج عند الهرس، لا تملأ الطنجرة أو الوعاء لأكثر من نصفها بالطعام.
- لا تقوم بتحضير أكثر من دفعة واحدة بدون توقف.
- اترك الجهاز يبرد لمدة 4 دقائق قبل استمرار التحضير.

مثال لوصفة: بطاطاً مهروسة

- 1 كجم بطاطاً مطبوخة
- 200 مللي حليب دافيء
- ضع البطاطا في وعاء وقم بالهرس لمدة 30 ثانية 3/4 ضغطة على مفتاح السرعة الذكي
- أضف الحليب. تابع الهرس لمدة 30 ثانية أخرى.

ملحق المفرمة (D)

تُعد المفرمة (10) هي الأفضل لفرم الجبن الصلب والبصل والأعشاب والثوم والخضروات والخبز والمكسرات والبندق.

استخدم المفرمة (10) «hc» للحصول على نتائج جيدة. ولكنها ليست مناسبة لفرم اللحوم.

تأكد من عدم تجاوز كمية المكونات أعلى من الحد الأقصى للمفرمة «ch». أقصى زمن تشغيل للمفرمة «ch» هو: دقيقة واحدة للكميات الكبيرة من المكونات الرطبة، 30 ثانية للمكونات الجافة أو الصلبة. ملاحظة: اترك فاصلاً زمنياً لا يقل عن 3 دقائق قبل التشغيل مرة أخرى (لمنع حدوث أي أعطال). الإيقاف الفوري للتحضير عند انخفاض سرعة المотор وأو عند حدوث اهتزازات قوية.

راجع دليل التحضير لأقصى الكميات والفترات الزمنية الموصى بها والسرعات.

قبل الاستخدام

- قم بقطع الطعام مسبيقاً إلى قطع صغيرة لتنقطيع أسهل.
- أزل آية عظام وأنسجة وغضاريف من اللحم لتساعد في حماية الشفرات من التلف.
- تأكد من إيقاف الحلقة المطاطية المانعة للانزلاق (10d/11e) أسفل وعاء المفرمة.

التحجيم والتتشغيل

- أزل الخطاء الواقي من الشفرة بحرص.
- عُتبر الشفرة (10b) حادة للغاية! لا تمسك الشفرة إلا من الجزء البلاستيكى العلوى واستخدمها بحرص.
- ضع الشفرة في منتصف وعاء المفرمة (10c). اضغط عليه في الأسفل وقم بلفه حتى يتم تأمينه في مكانه.
- املأ المفرمة بالطعام وضع عليه الغطاء (10a).
- قم بمحاذاة المفرمة مع جزء المotor (4) واضغطهما معاً.
- لتشغيل المفرمة، قم بتشغيل الجهاز. أثناء التحضير، امسك جزء المotor بيد واحدة ووعاء المفرمة بيد الأخرى.
- قم بفرم الأطعمة الصلبة دائمًا بالسرعة الكاملة (مثل جبنة البارميزان).
- عند اكتمال الفرم، افصل الطاقة واضغط على أزرار التحرير (5) لفصل جزء المotor.

• وبعد الاستخدام، افصل الطاقة واضغط على أزرار التحرير EasyClick Plus لفصل جزء المotor. ثم اسحب الخفاق خارج علبة تووس السرعة..

خطوات للحصول على أفضل النتائج

- حرك الخفاق في اتجاه عقارب الساعة أثناء مسكة بمقبض طفيف.
- لتفادي تطاير المكونات، قم بالتشغيل ببطء واستخدم ملحق الخفق في حاويات أو أوعية عميقه.
- ضع الخفاق في وعاء ثم شغل الجهاز فقط.
- تأكيد دائمًا من نظافة الخفاق ووعاء الخليط وخلوهما من الدهون قبل خفق بياض البيض. أخفق ما يصل إلى 4 بياض بيض.

مثال لوصفة: القشدة المخفوقة

- 400 ملي كريمة مبردة (تحتوي بحد أدنى على 30% من الدهون، 8 درجة سليزيوس)
- ابدأ بسرعة منخفضة (بالضغط الخفيف على المفتاح) ثم زود السرعة (بالضغط أكثر على المفتاح) أثناء الخفق.
- استخدم دائمًا كريمة مبردة تقنية لتحقيق حجم أكبر والحصول على المزيد من الاستقرار عند الخفق.

ملحق الهرس (C)

يمكن استخدام ملحق الهرس لهرس الخضروات والفواكه المطبوخة مثل البطاطا والبطاطا الجلوة والمطاطم والخوخ والتفاح.

قبل الاستخدام

- لا تهرس الطعام الصلب أو غير المطهو، لأن هذا قد يتسبب في تلف الوحدة.
- قم بتنقش وإزالة آية نوايا أو أجزاء صلبة؛ قم بطيهي وتجفيف الفواكه/الخضروات ثم هرسها.

التحجيم والتشغيل

- ثبت علىة تووس السرعة (9) في العمود (9 ب) من خلال لفه في اتجاه عقارب الساعة حتى يتم تأمينه في مكانه.
- اقلب ملحق الهرس من أعلى إلى أسفل وقو بتركيب المقلب (9 ج) في الفتاحة المركبة ولفه عكس اتجاه عقارب الساعة لتشبيهه. (إذا لم يتم تركيب علبة تووس السرعة بشكل صحيح، فإن المقلب لن يكون مستقرًا بأمان في مكانه).
- قم بمحاذاة ملحق الهرس المُجمَع مع جسم المotor واضغط على الجزيئين معاً. وصل الجهاز بالقباسين.
- قم بغمر ملحق الهرس داخل المكونات وقم بتشغيل الجهاز.
- من خلال حركة طفيفة من الأعلى إلى الأسفل، قم بتحريك ملحق الهرس خلال المكونات حتى تصل إلى درجة الهرس المطلوبة.
- قم بتحريك مفتاح السرعة الذكي وتتأكد من أن ملحق الهرس توقف تماماً عن الدوران قبل إزالته من الطعام.
- بعد الاستخدام، قف بفصل الجهاز. قم بفك المقلب (9 ج) عن طريق لفه في اتجاه عقارب الساعة.
- اضغط على أزرار التحرير EasyClick Plus لفصل ملحق الهرس من جزء المotor. افصل علبة تووس السرعة من العمود عن طريق لفه عكس اتجاه عقارب الساعة.

تحذير

- لا تستخدم ملحق الهرس في طنجرة على نار مباشرة.
- ارفع الطنجرة دائمًا من على النار واتركها لتبرد قليلاً.

أخرج الوحدة من الكرتونة. أزل كل القطع من العبوة. أزل آية تسميات من الممكن وجودها على الوحدة (لا تقم بإزالة لوحه التقييم).

نور دليلي

يوضح النور الدليلي (1) حالة الجهاز عند توصيله بـ مأخذ كهربائي.

نور دليلي	حالة الجهاز / التشغيل
وميض لونه أحمر	يعتبر الجهاز جاهزاً للاستخدام.
لون أحضر ثابت	يتم تحرير الجهاز (يتم ضغط زر تحرير المفتاح) ويفمن تشغيله
لون أحضر ثابت	تحذير مبكر بخصوص فرط التسخين. يبطئ المotor تدريجياً حتى يصل إلى إيقاف التشغيل.
لون برتقالي ثابت	دع الجهاز يبرد لمدة ساعة واحدة. يصبح جاهزاً للاستخدام مرة أخرى عندما يووضع النور الدليلي باللون الأحمر.

إذا انخفضت السرعة القصوى عند التحميل الثقيل والتشغيل لفترات طويلة، فإنه لا يزال بإمكانك إنهاء التجهيز الخاص بك، ولكن يجب أن تترك الجهاز يبرد بعد ذلك.

طريقة استخدام الجهاز

مفتاح السرعة الذكي لسرعات مختلفة

بضغطه واحدة، تصل إلى جميع السرعات. وكلما ضغطت أكثر، تصل إلى سرعة أعلى. وكلما ارتفعت السرعة، كلما حصلت على نتائج فرم وخلط أكثر دقة وسرعة.

التشغيل بيدي واحدة: يتيح لك مفتاح السرعة الذكي (3) تشغيل الجهاز والتحكم في السرعة بيدي واحدة.

تشغيل خلاط اليدوي

الاستخدام الأول: أزل قفل النقل من جزء المотор (4) عن طريق سحبه إلى الشريط الأحمر.

التشغيل (A)

يأتي الجهاز مزوداً بزر أمان لتحرير مفتاح السرعة الذكي. لتشغيله بأمان، اتبع هذه النقاط:

- اضغط على زر الأمان (2) بإبهامك. سيتحول النور الدليلي إلى لون أحضر ثابت.

اضغط على مفتاح السرعة الذكي على الفور وأض بيده على السرعة المطلوبة. ملاحظة: إذا لم يتم الضغط على مفتاح السرعة الذكي في غضون ثانية، فلا يمكن تشغيل الجهاز لأسباب تتعلق بالسلامة.

سيووضع النور الدليلي باللون الأحمر. لتشغيل الجهاز، ابدأ مرة أخرى مع إجراء الخطوة الأولى.

- ليس من الضروري أن يجعل زر الأمان مضغوطاً أثناء التشغيل.

ملحق الخفق (B)

استخدم الخفاق فقط لخفق القشدة، وضرب بياض البيض وإعداد الكيك الإسفنجي والحلوي الجاهزة.

التحميي والتشغل

- ثبت الخفاق (8) (ب) بعلبة تروس السرعة (8) أ.
- قم بمحاذاة جسم الموتور بملحق الخفق المجمّع وادفع القطع معًا حتى تسمع صوت نقرة.

عمود ActiveBlade

يتم تزويد الخلط اليدوي بـ عمود ActiveBlade يُمكّن السكينة من أن تمتد إلى قاع الإناء جرسى الشكل. يتم إجراء الضبط تقليدياً عن طريق الضغط المطلوب في مهام الخلط، خصوصاً بما يتاسب مع خلط الأطعمة الصلبة مثل الفواكه الطازجة والخضروات.

يعتبر أيضاً مناسباً جداً لإعداد المغمسات والمرق وإضافات السلطة والوصوص وطعم الأطفال بالإضافة إلى المشروبات والعصائر ومخفوقات الحليب.

للحصول على أفضل نتائج للخلط، استخدم أعلى درجات السرعة.

التحميي والتشغل

- ثبيت عمود ActiveBlade (6) بجزء المотор حتى تسمع صوت نقرة.
- ضع عمود ActiveBlade داخل الخليط ليتم خلطه. ثم شغل الجهاز كما هو موضح أعلاه.
- اخلط المكونات حتى تصل إلى الكثافة المطلوبة من خلال حركة لطيفة من الأعلى إلى الأسفل. سوف يتم الضغط على عمود ActiveBlade وستتمدد الشفرة وفقاً للضغط المطبق.
- وبعد الاستخدام، أفصل الخلط اليدوي واضغط على أزرار التحرير لفصل عمود الخلط (5) EasyClick

تحذير

- لا تدع السوائل أو المكونات تتجاوز الخط الأخضر لعمود الخلط.
- إذا كان استخدام الجهاز لإعداد طعام البوريه الساخن في الطنجرة أو الوعاء، فقم بإزالة الطنجرة أو الوعاء من المصدر الساخن وتأكد من أن السائل لا يبلغ. اترك الطعام الساخن يبرد قليلاً لتجنب مخاطرة التعرض للحرق.
- لا تترك الخلط اليدوي يوضع في وعاء ساخن على الموقد عند عدم استخدامه.
- لا تخذل عمود ActiveBlade في قاع الأوعية والأواني.

مثال لوصفة المايونيز

- 250 جرام زيت (زيت عباد الشمس مثلاً)، بيضة وصفار بيضة أخرى، 1-2 ملعقة طعام خل، ملح وفلفل للطعم
- ضع جميع المكونات (في درجة حرارة الغرفة) في الدورق بالترتيب المذكور أعلاه.
- ضع الخفاق اليدوي في قاع الدورق. قم بإجراء الخلط بأقصى سرعة حتى يبدأ بالتحول إلى لون الحليب.
- أثناء تشغيل الخلط اليدوي، ارفع العمود ببطء لأعلى الخليط ثم ازله مرة أخرى لدمج باقي الزيت. ملاحظة: زمن الخلط: تقريراً 1 دقيقة للسلطات وما يصل إلى دقيقة للحصول على مايونيز أثخن (مثل المغمسات).

ملحق الخفق (B)

استخدم الخفاق فقط لخفق القشدة، وضرب بياض البيض وإعداد الكيك الإسفنجي والحلوي الجاهزة.

التحميي والتشغل

- ثبت الخفاق (8) (ب) بعلبة تروس السرعة (8) أ.
- قم بمحاذاة جسم الموتور بملحق الخفق المجمّع وادفع القطع معًا حتى تسمع صوت نقرة.

- يرجى تنظيف كل الأجزاء قبل أول استخدام أو على النحو المطلوب، مع اتباع الإرشادات الموجودة في قسم الرعاية والتنظيف.

تم تصميم منتجاتنا لتلبى أعلى معايير الجودة والقابلية لأداء الوظائف والتصميم. ونأمل في أن تستمتع بجهاز Braun الجديد الخاص بك لأقصى درجة.

الأجزاء والملحقات

نور دليلي	1
زر أمان	2
مفتاح سرعة ذكي / سرعات مختلفة	3
جزء موتور	4
EasyClick Plus	5
عمود	6
دورق خلاط	7
ملحق خفق	8
علبة تروس السرعة	a
خفاقة	b
ملحق هرس	9
علبة تروس السرعة	a
عمود هرس	b
مقبل	c
ملحق مفرمة 350 ملي «ch»	10
غطاء	a
شفرة تقطيع	b
وعاء مفرمة	c
حلقة مطاطية مانعة للانزلاق	d
ملحق مطحنة القهوة والتوايل طاز	11
غطاء مزود بوصلة	a
سكين المطحنة	b
وعاء	c
قاعدة مانعة للانزلاق / غطاء	d
ملحق جهاز تحضير الطعام 2000 مل مع قطاعات «lpdf»	12
غطاء (مزود بمندوتوس تروس)	a
وصلة جزء المотор	b
دافع	c
أنبوب تغذية	d
مزلاج الغطاء	e
لوحة الحماية من الرذاذ	f
حلقة مطاطية مانعة للانزلاق	g
شفرة تقطيع	h
خطاف عجن	i
غطاء شفرة التقطيع	j
أداة العجين (PF)	k
أخطاف العجين (القطاعة)	l
شفرة القطاعة	m
قاعدة القطاعة	n
دافعة التنظيف	o
حامل الأداة	p
(i) أداة شرائح (ناعمة وخشنّة)	
(ii) أدوات التقطيع (ناعمة وخشنّة)	
(iii) أدلة جولييان	
قرص أصابع البطاطا المقلية	q
محور القرص	r

قبل الاستخدام

يرجى قراءة التعليمات كاملة بعناية قبل استخدام الجهاز.

تنبيه



- الشفرات حادة للغاية! لتجنب الإصابات، يرجى التعامل مع الشفرات بحرص شديد.
- يجب توخي الحذر عند التعامل مع شفرات القطع الحادة، وتفریخ الوعاء أثناء التنظيف.
- يمكن استخدام هذا الجهاز بواسطة الأشخاص ذوي الإعاقات الجسدية أو القدرات النفسية أو العقلية المحدودة أو من لديهم خبرة قليلة ومعرفة محدودة، وذلك إذا تم إرشادهم أو تدريتهم على استخدام الجهاز بطريقة آمنة، وإذا كانوا على دراية بالمخاطر التي ينطوي عليها استخدام الجهاز.
- يجب ألا يبعث الأطفال بالجهاز.
- يجب ألا يستخدم الأطفال هذا الجهاز.
- يجب إبقاء الأطفال بعيداً عن الجهاز وعن سلك التيار الكهربائي الرئيسي الخاص به.
- إذا كان سلك التيار الكهربائي تالفاً، فيجب استبداله بواسطة جهة الصنْع، أو وكيل الخدمة التابع لها، أو بواسطة شخص يتمتع بخبرات فنية مماثلة، وذلك بعرض تقادير آية مخاطر.
- يجب دائمًا إيقاف تشغيل وفصل لجهاز عند تركه دون رقابة وقبل التركيب وحال التجميغ والفك والتنظيف والتخزين.
- قبل توصيل الجهاز بמאخذ، يجب التتحقق من أن الجهد الكهربائي للتيار لديك يتوافق مع قيمة الجهد الكهربائي المطبوع على الجزء السفلي من الجهاز.
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط ولأغراض تحضير الكميات المنزلية الطبيعية.
- لا تستخدم الجهاز لأي غرض آخر غير الغرض الموضح في دليل المستخدم. أي سوء استخدام قد يسبب إصابة محتملة.
- لا تستخدم أي جزء من هذا الجهاز داخل الميكروويف.

